
RWB II PLUS PARTS LIST

Description	Frick Part #	Notes
RWB II PLUS SBC	333Q0000547	REV E UPGRADE
RWB II PLUS SBC	333Q0000547	REV D BOARD
RWB II PLUS LCD DISPLAY	333Q0000068	LCD DISPLAY
RWB II PLUS KEYPAD	640D0011H01	KEYPAD AND GASKET
RIBBON CABLE 26 CON.	111Q0280930	SBC TO LCD
RIBBON CABLE 12 CON.	640B0019H01	SBC TO KEYPAD
FUSE 5 AMP	333Q0000117	INPUT AND OUTPUT FUSES
FUSE 1.5 OR 2 AMP	333Q0000573	REPLACES F1 AND F2
TEMP PROBE	111Q0280818	TP2 REG. ACC.
TEMP PROBE	640A0035H01	BULLET STYLE PROBE
BATTERY KIT	640A0020G01	3 PACK AND CABLES
OUTPUT MODULE	111Q0281061	BLACK MODULE
INPUT MODULE	333Q0000116	YELLOW MODULE

RXB/RDB PARTS LIST

Description	Frick Part #	Notes
RXB/RDB SBC BOARD	333Q0000548	REV D BOARD
RXB/RDB LCD DISPLAY	333Q0000068	LCD DISPLAY
RXB KEYPAD	640D0012H01	RXB KEYPAD
RDB KEYPAD	640D0013H01	RDB KEYPAD
RIBBON CABLE 26 CON.	111Q0280930	TO LCD
RIBBON CABLE 12 CON.	640B0019H01	TO KEYPAD
FUSE 5 AMP	333Q0000117	INPUT AND OUTPUT FUSES
FUSE 1.5 OR 2 AMP	333Q0000573	REPLACES F1 AND F2
TEMP PROBE	111Q0280818	TP2 REG. ACC.
TEMP PROBE	640A0035H01	BULLET STYLE PROBE
BATTERY KIT	640A0020G01	3 PACK AND CABLES
INPUT MODULE	111Q0281061	YELLOW MODULE
OUTPUT MODULE	333Q0000116	BLACK MODULE

RXF PARTS LIST

Description	Frick Part #	Notes
RXF SBC BOARD	333Q0000549	REV D BOARD
RXF LCD DISPLAY	111Q0281048	LCD DISPLAY
RXF KEYPAD	640D0010H01	RXF KEYPAD
RIBBON CABLE 14 CON.	640A0019H01	TO LCD
RIBBON CABLE 12 CON.	640B0019H03	TO KEYPAD
TEMP PROBE	640A0035H01	BULLET STYLE PROBE
TEMP PROBE	111Q0280818	TP2 REG. ACC.